


# Oticon Hearing Instruments and DAI/FM combinations 2004

Hearing Aid	DAI Adaptor		FM Adaptor
	Low Level Input	High Level Input	FM Receivers
 <b>Oticon Syncro</b>	Bodyworn FM systems e.g. Solaris	TV, stereo, MP3 player, CD player, Computer	LEXIS receivers and other ear-level plug-in receivers
 <b>Adapto, Gaia, Atlas (Plus) Direct, GO Direct, DigiFocus II (all V2*), Digilife.com (all V2*)</b> <i>* if not marked V2 on battery door, aid must be sent to Oticon for n/c modification.</i>	<b>AP 800</b> 399-51-480-00* Transparent  <i>* includes tool for adaptor lock mechanism * input levels are set manually</i>	<b>AP 501</b> 399-51-440-03* Transparent  <i>* includes tool for making hole in battery door</i>	<b>FM 8</b> 399-51-470-00* Transparent  <i>* includes tool for adaptor lock mechanism</i>
 <b>DigiFocus II Super Power 300P, E30P, E30V, E31V</b>	<b>AP 502</b> 399-51-441-04* Transparent  <i>* includes tool for making hole in battery door</i>	<b>AP 201</b> 399-50-360-05 Beige  <b>AP 202</b> 399-50-370-07 Beige 	<b>FM 5</b> 399-51-170-07* Transparent  <i>* includes tool for making hole in battery door</i>
	<b>FM 3</b> 399-51-180-09* Transparent  <i>* includes tool for making hole in battery door</i>		

Hearing Aid	DAI Adaptor		FM Adaptor
	Low Level Input	High Level Input	FM Receivers
 <b>DigiFocus, Digilife, Primofocus, Personic (except 430)</b>	Bodyworn FM systems e.g. Solaris	TV, stereo, MP3 player, CD player, Computer	LEXIS receivers and other ear-level plug-in receivers
 <b>Atlas (Plus), GO, Ergo, Swift</b>	<b>AP 401</b> 399-50-276-02 Transparent 	<b>AP 402</b> 399-50-286-04 Transparent 	<b>FM 4</b> 399-51-130-08* Transparent  <i>* includes tool for making hole in battery door</i>
 <b>SUMO XP, E, Swift 120+</b>	<b>AP 600</b> 399-50-460-06* Transparent 	<b>AP 700</b> 399-50-900-08* Grey  <i>* input levels are set manually</i>	<b>FM 6</b> 399-50-450-04* Transparent  <i>* includes tool for adaptor lock mechanism</i>
 <b>Multifocus Classic 380P, 390PL, E35, E35F, E37, E37F, E38P, E39PL</b>	<b>AP 301</b> 399-50-340-00 Beige 	<b>AP 302</b> 399-50-350-03 Beige 	<b>FM 7</b> 399-50-920-02 Grey  <b>FM 3</b> 399-51-180-09* Transparent  <i>* includes tool for making hole in battery door</i>

Cord, Monaural	Handheld MIC 30, MIC 32	383-58-810-02
Cord, Binaural	Handheld MIC 30, MIC 32	383-58-830-06
Cord, Monaural	CD or MP3 Players, computer, etc	383-58-842-00
Cord, Binaural	CD or MP3 Players, computer, etc.	383-58-852-03
Cord, Monaural	Open end 1m.	383-08-003-00
Cord, Monaural	Open end, 6m.	383-08-004-01

## DAI Cords