
























Oticon Hearing Instruments and DAI/FM compatibility Overview 2007

	DAI Adaptor		FM Adaptor	FM receiver	Modes of operation
	Low Level Input	High Level Input			
 Hearing Aid	Bodyworn FM solutions e.g. Amigo R5	TV, stereo, MP3 player, CD player, Computer	Adaptor for AMIGO receivers and other ear-level receivers	Universal and dedicated AMIGO receivers	Default modes of operation when using DAI and FM adaptors
 Epoq	AP 900 399-50-520-08 Transparent 				Automatic DAI detect When AP900 is attached, 2 programs will automatically be added to the HA: - DAI + HA (default) - DAI only
 Oticon Syncro, Oticon Safran, Oticon Tego Pro, Oticon Tego, Oticon GoPro	AP 800 399-51-480-00 Transparent  Includes tool for adaptor lock Input levels are set manually		FM 8 399-51-470-00 Transparent  Includes tool for adaptor lock	RI/R2 Silver 	Automatically adds 2 programs to HA: - DAI/FM + HA (default) - DAI/FM only Amigo switch positions: ○ ○ = HA + FM (recommended) ○ = HA + FM ● = HA only/FM off
 Adapto, Gaia, Atlas Plus Direct, GO Direct	AP 501 399-51-440-03 Transparent  Includes tool for making a hole in battery door	AP 502 399-51-441-04 Transparent  Includes tool for making a hole in battery door	FM 5 399-51-170-07 Transparent  Includes tool for making a hole in battery door	RI/R2 Silver 	HA positions: M = HA + FM T = telcoil * Amigo switch positions: ○ ○ = HA + FM ○ = FM only ● = HA only/FM off
 Atlas, Atlas Plus, GO, (all except Direct) Ergo, Swift	AP 600 399-50-460-06 Transparent  Includes tool for adaptor lock Input levels are set manually		FM 6 399-50-450-04 Transparent  Includes tool for adaptor lock	R1/R2 Silver 	HA positions: M = HA + FM T = telcoil * Amigo switch positions: ○ ○ = HA + FM ○ = FM only ● = HA only/FM off
 Sumo DM, Sumo XP, Sumo E, Swift 120+	AP 700 399-50-900-08 Grey  Input levels are set manually		FM 7 399-50-920-02 Grey 	R1/R2/R7 Silver 	HA positions*: 1 = HA 2 = HA + FM 3 = FM only Amigo switch positions (R7): ○ = ON ● = OFF Amigo switch positions (FM7+R1/R2): ○ ○ = HA + FM (recommended) ○ = HA + FM ● = HA only/FM off
 CI processors from various manufacturers			FM-CI Cochlear implant adaptor 140-08-110-00 	R1/R2 Silver 	See Oticon CI compatibility guides

* other configurations are possible using Genie

DAI Cords

Cord, Monaural	Handheld MIC 30, MIC 32	383-58-810-02
Cord, Binaural	Handheld MIC 30, MIC 32	383-58-830-06
Cord, Monaural	CD or MP3 Players, computer, etc	383-58-940-09
Cord, Binaural	CD or MP3 Players, computer, etc.	383-58-941-00
Cord, Monaural	Open end 1m.	383-08-003-00
Cord, Monaural	Open end, 6m.	383-08-004-01

		169-187 MHz	216-217 MHz
FM receiver order information:	R1:	140-06-000-00	140-06-100-00
	R2:	140-06-200-00	140-06-300-00
	R7:	140-06-600-00	140-06-700-00